

The **ExtraNET μ CC** processor monitors the Globalstar modem and provides re-initialization and self monitoring to provide reliable communications to remote facilities. Easy configuration allows for up to 8K bytes of initialization strings to satisfy virtually any setup requirements you might have. The “watch dog” times all active satellite sessions and will automatically disconnect if you exceed your predetermined maximum allowed connection to prevent expensive “hung sessions” on the Globalstar network.

Product Highlights:

- -Automatic detection of modem reset and re-initialization of user configuration
- -Call timer and user configurable maximum allowed connection
- -Menu driven easy configuration using terminal type program (ie. HyperTerminal)
- -8K bytes of nonvolatile flash memory for initialization commands
- -Rugged die cast Aluminum Enclosure
- -Weather proof electrical connections
- -Low Power operation
- -Extended Temperature Range
- -Functional in over 100 countries for coverage in most countries world wide
- -1 year warrantee
- -Complete support for assuring successful integration in your application

